



# Pond Power LED 3W – 6W

User manual

EN

# Function

The Pond Power LED is a spot light for use in the garden, in the pond and varying fountain installations.


## Installation

You can use the Pond Power LED spot with the supplied base or ground pin.

**When placed in the pond:** Slide the spot light onto the base and place it on the pond bottom. Make sure the spot light is stable.

**When placed in the garden:** Slide the spot light on the ground pin and insert the pin almost completely into the ground.

You can also use the base on a hard surface.




- Connect the cord to the adapter and hand tighten the union nut to prevent moisture from entering.
- Plug the adapter into the socket.
- Make sure that no one can trip over the cord and that the cord cannot be damaged.
- Tilt and rotate the spot light in the desired direction.



# Using the optional SuperFish Twilight Sensor

You can use the optional SuperFish Twilight Sensor (Art. 06070229), which automatically switches the LED lighting on and off when the outside becomes dark and light respectively. You can easily connect it between the cord and adapter.



## Maintenance



Always remove the plug from the socket before carrying out maintenance

- Never try to open the spot light, as this could result in the device no longer being waterproof.
- The LEDs cannot be replaced. Replace the lighting if the LEDs no longer work.
- If necessary, clean the spot light with a damp cloth.
- If the adapter is broken, it can be replaced. Please contact your dealer.

*There are two different versions of the SuperFish Pond Power LED, order the correct adapter:*

*SF Pond Power LED Ballast 3W (Art. 06070410) and SF Pond Power LED Ballast 6W (Art. 06070415).*

*Only use the original SuperFish adapter.*

# Safety & Warranty

[View the Safety & Warranty »](#)